ANGELS HORN Quick Start Guide HP-H003



Installation

1



2



3



4



5

Careful!





OK → 6

NOT OK → 5

6

Careful !



7



OK → 8

NOT OK → 5

8



9



10


PHONO OUT
R
L
PHONO OUT
LINE OUT
DC IN
12V 500mA
Active Speaker
Amplifier


LINE OUT
R
L
PHONO OUT
LINE OUT
DC IN
12V 500mA
Active Speaker

11


DC IN
12V 500mA

12


Please use it with RPM adapter

13


33 RPM
ANGELS HORN


45 RPM
ANGELS HORN

Operation

14



15



16



17



18



19



20

If there is too little or no sound when playing, please increase the weight of the counterweight.



Stop the turntable











Note:

1. When the record is played to the end, it will enter the inner closed loop and continue to rotate, and you need to manually raise the tonearm to stop it.

2. After power on, the blue LED light flashes to indicate that the Bluetooth is searching for devices, and the steady light indicates that the Bluetooth is paired with the device. If it is not paired for two minutes, the blue light turns to red, and the red light is the power indicator.

ANGELS HORN
HP-H003
support@angelshorn.com